## **Pressure Treatments**

### **Low Pressure**

#### UC1

Suitable for dry internal timbers that may suffer from insect damage, such as floor joists and truss rafters.

#### UC2

Suitable for internal timber that may be more suseptible to wetting, such as tile battens and CLS framing.





# High Pressure UC3A

Suitable for outdoor use and above ground use as the timber is coated at this level.

#### UC3B

Uncoated - this is suitable for external timber that remains above ground, such as fence rails.

#### UC4

Any timber that comes in contact with water or direct soil must be treated to this level. Including fence posts and decking structures sucken in the ground.